



FITTING INSTRUCTION FOR PFF85-204

Thank you for purchasing one of the advanced ranges of POWERFLEX polyurethane suspension bush kits.

Once old bushes have been removed including the outer sleeve. This may require the use of a press, or put a hacksaw blade through the void in the bush and cut the outer sleeve. Always clean faces and bores to ensure correct fit

The Golf front wishbone rear bushes will need to be pressed into position. This can be done between the jaws of a vice. Place the smaller diameter into the radiused opening on the wishbone with some of our lubricant around the hole to aid in fitting and press through the arm, lubricate the outside of the metal sleeve and press it into the hole in centre of the bush. The bush will fit a different way up on each side of the car, this is correct. Place special washers over raised locating ring above and below where the bush will fit. Slid arm into position, before fitting bolt place small locating rings into sub frame to centralize bolt. Fit bolt and tighten to manufactures specification.

Should you experience any technical difficulties in any way please contact our technical Hotline.

(+44) 01895 460033



Bush Correctly Installed Into Arm



Apply Supplied Lubricant To Sleeve & Push In



Place Into Position The 2 Washers.



Locate Small Sleeves Into Both Sides Of Bolt Hole